Lab 7 Simulation of Dipole Antennas and Waveguide Antennas

- 1. Simulate a dipole antenna with different lengths. Try 0.01 λ, 0.1 λ, 0.5 λ, 1.5 λ and 5 λ. You should use two PEC cylinders to represent the dipole and use a very tiny gap between them. Make the diameter of the cylinder much smaller than its length. Plot 2D (in two principle planes) and 3D patterns. Check the near-field fields and far-field fields to see if the former results in mainly reactive power and the latter results in real power.
- 2. Put a 0.5-λ dipole antenna very close to a large flat PEC plane and make the dipole parallel to the PEC. Set the distance between them to be even smaller than the cylinder radius. Check the far-field fields and compare with those of the corresponding case in topic 1, from which you can conclude if a dipole near a PEC plane radiates or not.
- 3. Simulate a two-dipole antenna array with $0.5-\lambda$ dipoles. Arrange them in the way shown in Figure 6.1 in the textbook. Set $\beta = 0$. Use spacing of $\lambda/4$ to observe how well the simulated 2D patterns agree with the theoretically calculated one. Plot simulated (three cases) and theoretically calculated 2D patterns together.





Figure 6.1 Geometry of a two-element array positioned along the z-axis.

$$\beta = -kd\cos\theta_0$$

4. Use the setup of $d = \lambda/4$ in topic 3. Try different phases with $\beta = 90^{\circ}$. Plot simulated and theoretically calculated 2D patterns together for each case. You can take advantage of the "Array Wizard" function of the software for some topics involving

<mark>arrays.</mark>

- 5. Simulate an X-band rectangular waveguide antenna with one end set as a wave port and the other open. Use the frequency of $1.5f_c$ for TE₁₀ mode. Obtain its directivity and plot the 3D pattern.
- 6. Simulate an E-plane sectoral horn antenna fed by an X-band rectangular waveguide. Use the frequency of $1.5f_c$ for TE₁₀ mode. According to the geometry shown in Figure 13.2(b), make the distance from the left end of the waveguide to the virtual line source to be $2\lambda_8$. Use $\rho_1 = 8\lambda_0$ and total flaring angle of 30°. Set up a wave port at the waveguide aperture and make the horn aperture to be radiating. Place a field monitor plane in two xy cross sectional planes in the waveguide and the horn part $(4\lambda_0$ to the aperture), respectively, and plot the electric fields on them. Obtain the directivity and compare it with that of a waveguide antenna working at the same frequency. Plot the 3D pattern.



(b) E-plane view

Figure 13.2 *E*-plane horn and coordinate system.